

Instructions for “Installs”

The stuff on the platform is just 3 DVD players and 3 projectors.

I only gave you the remote for the large projector, to save confusion.

The DVD players should just stay on, and playing, for the entire time the exhibition is up. Seriously— the DVD’s were 35 cents, and the players were 35 dollars—if they wear out, I’ll get more.

When first turned on, the DVD’s will show a menu that says something like “Neal McDonald Kelly01, September 22 2008, Press “enter” to start.”

If you see this, press the “play” button on the DVD player. The DVD’s are built to loop endlessly once started.

Again, just leave the DVD’s playing; you should only see the menus if the DVD’s have been accidently turned off or bumped.

The projectors should be turned off at night, solely to save the projector bulbs, which are expensive and a pain to replace. Probably no bulbs will burn out in the course of the exhibition, but if they do, please call me immediately.

Y’all have the large projector’s remote. It has big buttons labeled “on” and “off”, which work pretty well.

The large projector’s input comes from the yellow RCA “video” cable. You might have to switch between inputs before you see the DVD video.

The small projectors’ remotes don’t work. Please push the “power” buttons on top of the projectors to turn them off and on.

The small projectors take input from s-video. You might have to push their “input” buttons a few times to get them to switch to this.

Any other problems? Please call me in my office 410 455 2581 or my cellphone, 410 487 2928

Neal McDonald --- mcdo@umbc.edu